

HOW TO E-CLEAN K8 MACHINE

"E-CLEAN a minimum of every 2 weeks or twice a month".

 Things You Need: E-Cleaning Powder Discharge Plug Cleaning tank




Click Settings of your K8 Machine at the bottom of the LCD



• Select E-Cleaning



 After That, you will see another screen with E-Cleaning Instructions on Top and Yes or No options.



• Please select "Yes" to move the machine to step forward into E-Cleaning



 The next Screen E-Cleaning 1, get the tank of the machine, fill it up with 2 packs of Enagic E-Cleaning powder, add roughly 400ml of water to it then shake it well.









• On the next step, E-cleaning 2, Insert the tank and place the Cover on it and press okay.



• On the 3rd Step of E-cleaning, remove the filter from the unit and install the cleaning cartridge in its place and lock it down. Pre okay to move forward.







• On E-Cleaning Step 4, Install Please Plug the Red Acid Discharge Plug as provided with the machine and make sure to point the flex pipe in the sink.





• On Step 5, Press Start to Commence E-Cleaning, the machine will go in in a cycle of E-Cleaning for 3 hours which will be step 6



• Once it's done on step 7, please remove the red cap from the secondary hose and press okay.



• On step 8, please remove the cartridge and install the fill and press ok.








• On the 9th Step, remove the cleaning tank from the bottom of the unit and replace with enhancer tank. Press ok.





• On the Step 10, please run the water through the machine for 300 seconds to finish the rinsing.





• E-Cleaning Complete

Enagic Philippines Inc.

Unit 3 and 4, 16F A.T. Yuchengco Centre 26th and 25th Streets, Bonifacio Global City, 1634, Taguig City Tel: 8519 5508